

DVR1A1081



Security Systems

EN | Installation Instructions
Digital Recorder

FR | Manuel d'installation
Enregistreur numérique

DE | Installationshandbuch
Digital Recorder

ES | Manual de instalación
Grabador digital

NL | Installatiehandleiding
Digital Recorder

IT | Istruzioni sull'installazione
Registratore digitale

PT | Instruções de Instalação
Gravador Digital

PL | Instrukcja instalacji
Cyfrowy magnetowid

BOSCH



ENGLISH	3
FRANÇAIS	23
DEUTSCH	43
ESPAGÑOL	63
NEDERLANDS	83
ITALIANO	103
PORTUGUÊS	123
POLISH	143



1. SAFETY PRECAUTIONS	5
1.1 IMPORTANT SAFEGUARDS	5
1.2 FCC INFORMATION	6
2. INTRODUCTION	6
2.1 FEATURES	6
2.2 FRONT PANEL	7
2.3 REAR PANEL	8
2.3.1 Power	8
2.3.2 RS232 serial connector	8
2.3.3 IR remote control eye connector	8
2.3.4 Alarm connections	8
2.4 INTERCONNECTIONS	9
2.4.1 Multiplexers	9
2.4.2 Quads	10
2.4.3 Single camera	11
2.5 REMOTE CONTROL UNIT	12
3. OPERATION	13
3.1 INSTANT RECORDING	13
3.2 ALARM RECORDING	13
3.2.1 Pre-alarm recording	13
3.3 NORMAL PLAYBACK	13
3.4 SEARCH PLAYBACK	13
3.5 COPY	14
3.5.1 Still image copy	14
3.5.2 Copy to movie file	14
3.6 SECURITY LOCK SETTING	14
4. MENU SET-UP	15
4.1 MAIN MENU	15
4.2 CLOCK/LANGUAGE MENU	15
4.3 NORMAL RECORD MENU	15
4.4 ALARM RECORD MENU	15
4.5 TIMER MENU	16
4.6 BUZZER MENU	16
4.7 ARCHIVE MENU	17
4.8 SYSTEM SETTINGS MENU	17
4.9 PASSWORD MENU	18

5. SPECIFICATIONS	19
5.1 RS-232 INTERFACE	19
5.1.1 RS-232 control protocol	19
5.2 RECORDING TIME	20
5.3 TECHNICAL SPECIFICATIONS	21

1 SAFETY PRECAUTIONS



Danger

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of an uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



Warning

The exclamation mark within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



Caution

To reduce the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.

1.1 IMPORTANT SAFEGUARDS

1. Please read these safety instructions carefully.
2. Please keep this User's Manual for later reference.
3. Please disconnect this equipment from connector before cleaning. Don't use liquid or sprayed detergent for cleaning. Use moisture sheet or cloth for cleaning.
4. Make sure the voltage of the power source when connect the equipment to the power outlet.
5. All cautions and warnings on the equipment should be noted.
6. Never pour any liquid into opening, this could cause fire or electrical shock.
7. Never open the equipment. For safety reason, the equipment should only be opened by qualified service personnel.
8. If one of the following situations arises, get the equipment checked by a service personnel :
 - a. Liquid has penetrated into the equipment.

- b. The equipment has been exposed to moisture.
- c. The equipment has not work well or you can not get it work according to user's manual.
- d. The equipment has dropped and damaged.
- e. If the equipment has obvious sign of breakage.
9. Do not leave this equipment in an environment unconditioned, storage temperature above 50°C, it may damage the equipment.
10. Operation Ambient 40°C
11. Power cords : Use the proper power cord with correct attachment plug type. If the power source is 120 V AC, use a power cord that has UL and CSA approvals. If the power source is a 240 V AC supply, use the tandem (T blade) type attachment plug with ground conductor power cord that meets the respective European country's safety regulations, such as VDE for Germany. Plug need approval with VDE 0620, connector approval by VDE 0625, minimum 10A, power cord H05VV-F or VW-1,0.75 mm² x 3G should be used.

12.



Warning

To reduce the risk of fire or electric shock, this apparatus should not be exposed to rain or moisture and objects filled with liquids, such as vases, should not be placed on this apparatus.

13. The back of the recorder should only be removed by qualified maintenance and service personnel.
14. Danger of explosion if battery is incorrectly replaced. A lithium battery is located inside the enclosure of this recorder. Replace only with the same or equivalent type. Dispose of the replaced battery in an environmentally friendly way.
15. Keep ventilation openings free to avoid the recorder for overheating.
16. Do not place the recorder in the immediate vicinity of a heating source.
17. Do not install this equipment in a confined space such as a bookcase or similar unit.

Cleaning

You can clean the unit with a moist fluff-free cloth or shammy leather cloth.

Bosch has a strong commitment towards the environment. This unit has been designed to respect the environment as much as possible.

1.2 FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Note

Any change or modification not expressly approved by Bosch of the equipment authorization could void the user's authority to operate the equipment. For additional information or to speak to a representative, please contact the Bosch Security Systems location nearest you or visit our web site at www.boschsecuritysystems.com

2 Introduction

The DVR1A1081 Digital Video Recorder provides advanced recording and playback technology for CCTV systems. The DVR allows uninterrupted recording in either continuous or time-lapse modes for as long as a week or more. There are no video tapes to change or store, and frequent, costly VCR maintenance is eliminated.


The DVR can record at speeds up to 50/60 images per second with PAL/NTSC formats and replay events instantly. The DVR incorporates all the benefits of digital video recording, is simple to install, and operates just like a VCR. The highly efficient compression technology, as well as the superior clarity and detail of recorder images, make the DVR ideally suited for integration with a wide range of multiplexers.

2.1 Features

- Provides superior quality images
- Pre-Alarm image recording
- Time lapse and real time recording
- Refresh rate up to 50 images for PAL and 60 images for NTSC
- Quick Search by date/time, alarm events, and recording list
- Fast and slow playback of recorded video in various speeds
- On-screen setup menu and system timer
- Password protection
- RS-232 communication port
- Built-in M-JPEG compression/decompression with configurable quality
- Programmed with various time-lapse speeds
- Data can be stored on Compact Flash Card
- Remote control
- Compatible with Bosch and various other types of multiplexers.

2.2 Front panel

- 1** REC: Press to start recording (red light in key lights when unit is recording).
- 2** OSD: - Press once to display the time/date, disk usage and playback rate.
- Press a second time to display disk size, record position and play position.
- Press a third time to switch off the on-screen display.
- 3** STOP: Press to stop recording or playback.
- 4** PLAY: Press to start playback.
- 5** PAUSE: Press to pause the playback picture.
- 6** SEARCH: Press to enter the search menu.
- 7** Shuttle Ring:
In playback mode, turn Shuttle Ring clockwise to speed up or counterclockwise to slow down the forward or reverse play of the picture.
In pause mode, turn Shuttle Ring to move the picture slowly forward or reverse.
- 8** Jog Dial:
In playback mode, turn Jog Dial to select the playback speed.
In pause mode, turn Jog Dial to move forward or backward image by image.
In menu mode, turn Jog Dial to navigate through the menu pages or to select data values. Use together with the ENTER key to set menu values.
- 9** ENTER: Press to confirm a selection or a changed data value.
- 10** MENU: Press to enter or leave the setup menu.
- 11** Remote control IR receiver window.
- 12** ALARM: Indicator lights when an alarm occurs.
- 13** HDD: Indicator lights when hard disk drive is accessed.
- 14** Compact Flash card slot: Insert a Compact Flash Card. Press the black button beside the slot to remove the card.
- 15** COPY: Press to copy still picture or video stream onto Compact Flash card.



2.3 Rear panel

2.3.1 Power

Connect the power supply cable to the power socket at the rear of the unit. Use the power switch to switch the unit ON or OFF.

2.3.2 RS232 serial connector

Connect D-Sub 9-pin connector to the RS232 port if you want to control the unit remotely.

2.3.3 IR remote control eye connector

If the remote control IR receiver window at the front is hidden from view (if the unit is mounted in a cupboard), connect the optionally available extension IR cable to the remote control connector. Position the receiver eye so that it is in line-of-sight of the remote control unit.


2.3.4 Alarm connections

The ALM-IN and ALM-RST inputs can be set to Normally Open (N.O.) or Normally Closed (N.C.) in the Alarm record menu.

- GND:** Ground connection.
- ALM-IN:** Apply a signal* here to start alarm recording.
- ALM-RST:** Apply a signal* here to stop alarm recording.
- REC:** A high level external recording request signal* applied to this pin starts recording. When the signal drops to low, recording stops.
- NC1, NC2:** No connections.

* Signal


- switching voltage High: $> 2 \text{ Vdc}$
- switching voltage Low: $< 0.5 \text{ Vdc}$
- max. input voltage: 12 Vdc



The alarm output signals are:

- GND:** Ground connection.
- ALM-NC**:** When an alarm occurs, the connection between this pin and ALM-COM is open. Otherwise it is closed.
- ALM-NO**:** When an alarm occurs, the connection between this pin and ALM-COM is closed. Otherwise it is open.
- ALM-COM**:** Alarm common contact.
- VEXT:** Synchronization signal for multiplexer.
Output voltage: 5 Vdc
Output current: 100mA
- DISKFULL:** Disk full alarm output signal.
Output voltage: 5 Vdc
Output current: 100mA
- NC3, NC4:** No connections.

** contact voltage max: 24 Vdc
max. switching current: 2A dc



2.4 Interconnections


The DVR can be connected to a wide range of multiplexers, quads or directly to a camera.

2.4.1 Multiplexers

The drawing below shows how to connect a multiplexer to the DVR.

- Connect the monitor to the BNC socket marked Monitor Out on the rear of the DVR.
- Connect the main monitor output of the multiplexer to the BNC socket marked Monitor In on the rear of the DVR.

- Connect the VCR output of the multiplexer to the BNC socket marked Video In on the rear of the DVR.
- Connect the VCR input of the multiplexer to the BNC socket marked Video Out on the rear of the DVR.
- To synchronise switching with the multiplexer connect the VEXT and GND connections on the rear of the unit to the connector of the multiplexer. When the connections are made, refer to the system menu to select the type of multiplexer you are using.




2.4.2 Quads

The drawing below shows how to connect a quad without a VCR output to the DVR.

- Connect the monitor to the BNC socket marked Monitor Out on the rear of the DVR.

- Connect the video output of the multiplexer to the BNC socket marked Video In on the rear of the DVR.
- In the system menu set the multiplexer item to Off. To connect a quad with a VCR output, refer to the multiplexer connections.




2.5 Remote control unit

The remote control unit is an accessory that makes it easy to control the DVR from a distance. You can carry out the main operations using the remote control unit.

The keypad functions for the DVR are as follows:

- RECORD:** Press to start recording.
- STOP:** Press to stop recording or playback.
- PLAY:** Press to start playback.
- SEARCH:** Increase the speed by 2x, 4x, 8x, 16x, 32x, 640x, 2x . . .
- REWIND:** In playback mode, press to reverse playback (Search key increases reverse speed).
- STEP REW.:** Press to stop playback. Press again to step backward image by image.
- STEP FORW.:** Press to stop playback. Press again to step forward image by image.
- FORWARD:** In reverse playback, press for forward playback (Search key increases forward speed).



3 Operation

3.1 Instant recording

Press the Record key to start the recording immediately - the images are recorded on the hard disk.

- The recording rate and recording quality are set in the Normal record and Alarm record menus.

Press the Stop key to stop recording.

- Stop key can only be activated in recording mode.
- When the hard disk is full, the DVR stops recording automatically or overwrites from the beginning of the hard disk depending on the setting in the System Settings menu.

3.2 Alarm recording

The monitor image is recorded automatically when an alarm occurs and stops recording at the end of the alarm duration period. Instant recording and timer recording stop when an alarm occurs. If the unit is already recording then the recording quality does not change for alarm recording. Set the options for alarm recording in the Alarm record menu.

3.2.1 Pre-alarm recording

A buffer is used to pre-capture video for recording images just before an alarm is triggered. Pre-alarm recording only occurs if the unit is not already recording during the pre-alarm period. The recording quality in the pre-alarm period is the same as the recording quality before the alarm occurs. If the recorder is not recording before the alarm occurs, the recording quality in the pre-alarm period is the same as normal recording quality.

3.3 Normal playback

Playback

- Press PLAY key to start playing back the stored image from the last segment.
- Press STOP key to stop playing back.

Fast Forward

- Press PLAY key to start playing back.
- Turn the Shuttle Ring clockwise and fast forward playback starts. The speed is shown on the OSD (normal play speed, 2x, 4x, 8x, 16x, 32x, 640x).

Reverse Playback

- Press PLAY key to start playing back.

- Turn the Shuttle Ring counterclockwise and fast reverse playback starts. The speed is shown on the OSD (normal play speed, 2x, 4x, 8x, 16x, 32x, 640x).

Slow Forward Playback

- Press Pause key to freeze the playing back picture.
- Turn the Shuttle Ring clockwise and slow forward playback starts. The speed is shown on the OSD (>1/2, 1/4, 1/8, 1/16, 1/32, 1/64).

Slow Reverse Playback

- Press Pause key to freeze the playing back picture.
- Turn the Shuttle Ring counterclockwise to start slow reverse playback. The speed is shown on the OSD (<1/2, 1/4, 1/8, 1/16, 1/32, 1/64).

Lock displayed speed

- To lock the displayed speed, press the Enter key and then release the Shuttle Ring. If you turn the Shuttle Ring again, the speed returns to normal play speed.

Image advance Forward/Reverse

- Press Pause key to freeze the picture.
- Turn the Jog Dial clockwise to advance the picture image by image.
- Turn the Jog Dial counterclockwise to rewind the picture image by image.
- The image speed increases if the Jog Dial is turned quickly.

3.4 Search playback

Segment Search Playback

- Press the Search key to enter the Search menu.
- Move the cursor to BY SEGMENT LIST and press the Enter key to select file search.
- Move the cursor to the segment you want to playback (pAlarm: Pre-alarm record, Timer: Timer record).
- If the selection list is full, turn the Jog Dial clockwise to select the next page list.
- Press Enter to start playing back.

Alarm Search Playback

- Press Search key to enter the Search menu.
- Move the cursor to BY EVENT LIST and press the Enter key to select alarm search.
- Move the cursor to select the alarm image to be played back.
- If the selection list is full, turn the Jog Dial clockwise to select the next page list.
- Press Enter to start playing back the alarm images.

- The alarm image is played back from the pre-alarm period and stops at the end of alarm duration.

Date/Time Search Playback

- Press Search key to enter the Search menu.
- Move the cursor to BY DATE/TIME and press the Enter key to select file search.
- Move the cursor to the value you wish to select and press the Enter key.
- Turn the Jog Dial to increase or decrease the value and press the Enter key.
- Move the cursor to START SEARCH AND PLAY and press the Enter key and the playback starts from the date/time set in the menu.

If there is no image stored in the date/time specified then the unit automatically starts playing back from the nearest set time.

3.5 Copy

Insert a Compact Flash card (type I or II) into the Compact Flash slot on the front panel. When inserting the Compact Flash card, make sure that the direction of insertion is correct. Use only a Compact Flash card with a capacity of 16MB or higher.

The Compact Flash copy function is designed for copying short clips. A long clip can take quite a long time to copy.

Note

To improve the legibility of the copy messages, press the OSD key. Press the OSD key again to switch off the background.

3.5.1 Still image copy

- Press the Play key to start playing back.
- Press the Pause key to freeze the picture.
- Turn the Jog Dial clockwise or counterclockwise to move to the desired image.
- Press the Copy key to enter the copy mode.
- Turn the Jog Dial to select the desired camera image.
- While the image is displayed, press the Copy key again. The message "Copying ..." appears on the screen during the process. The message "Success" and the file identification appears on the screen after the file is copied.
- Press the STOP key to cancel copy.
- Press the Play key to continue playback.

Copied images are stored as a single picture in a JPG file format.

3.5.2 Copy to movie file

- Press the Play key to start playing back.
- Press the Copy key to enter the copy mode.
- Turn the Jog Dial to select the desired camera.
- While the image is displayed, press the Copy key again. The message "Copying ..." appears on the screen during the process.
- Press STOP key to end copy.
- The message "Success" and the file identification appears on the screen after the file is copied.
- Press the Play key to continue playback.

Copied images are stored as a movie picture in a MOV file format.

3.6 Security lock setting

Press the REC key for more than 5 seconds while in the record mode to lock all the keys on the front panel. (The Password must be set in the System Settings Menu to enable this feature.)

Press Stop key, the system asks for the password. If you enter the correct password, the locked keys are released.

4 Menu set-up

When system has been connected as described:

- Switch power on
- Allow some time for the system to load.
- Press the MENU key to enter the MAIN MENU.

When the main menu is displayed you see the different submenus where the settings can be changed.

To navigate through these menus, turn the Jog Dial clockwise or counterclockwise to scroll through the submenus. Press the ENTER key to open a submenu. In the submenus, continue using the Jog Dial and ENTER key to scroll through items and values and select them. To return to the main menu, scroll to the bottom of each submenu to the MAIN MENU item and select it by using the ENTER key.

4.1 Main menu

MAIN MENU	
CLOCK/LANGUAGE	>
NORMAL RECORD	>
ALARM RECORD	>
TIMER	>
BUZZER	>
ARCHIVE	>
SYSTEM SETTING	>

4.2 Clock/Language menu

CLOCK/LANGUAGE MENU	
DATE	2002-04-24
TIME	13:01:02
DATE FORMAT	YYYY-MM-DD
MENU LANGUAGE	ENGLISH
MAIN MENU	>

DATE: Year: 2000~2099 Month: 01~12 Date: 01~31
 TIME: Hour: 00~23 Minute: 00~59 Second: 00~59
 DATE FORMAT: Set the display order for Year (YYYY), Month (MM) and Day (DD)
 MENU LANGUAGE: English, German, French, Spanish, Italian, Portuguese, Dutch or Polish.
 MAIN MENU: Return to the main menu.

4.3 Normal record menu

NORMAL RECORD MENU	
RECORD SPEED	8 IPS
RECORD QUALITY	STANDARD
RECORD TIME	... HRS
MAIN MENU	>

SPEED : Select the record speed from 0.1 to 25/30 IPS.

QUALITY: There are six quality levels for recording

LOWER: 15 KB

LOW: 20 KB

BASIC: 25 KB

STANDARD: 30 KB

HIGH: 35 KB

SUPERIOR: 40 KB

RECORD TIME: Shows an estimate of the recording time available on disk for the selected speed and quality.

4.4 Alarm record menu

ALARM RECORD MENU	
ALARM OPERATION	ON
RECORD SPEED	50 IPS
RECORD QUALITY	STANDARD
ALARM-IN TYPE	N.O.
ALARM-RESET TYPE	N.O.
ALARM DURATION TIME	10 SECS
PRE-ALARM OPERATION	ON
RECORD SPEED	50 IPS
MAIN MENU	>

ALARM OPERATION:

ON : Record when alarm occurs.

OFF : Do not record when alarm occurs.

RECORD SPEED: Recording speed for the duration of the alarm.

The max. recording speed is 50/60 IPS (PAL/NTSC).

The min. recording speed is 0.1 IPS.

RECORD QUALITY: Recording picture quality when alarm occurs.

LOWER: 15 KB

LOW: 20 KB

BASIC: 25 KB

STANDARD: 30 KB

HIGH: 35 KB

SUPERIOR: 40 KB

ALARM-IN TYPE:

N.O. : Normally Open

N.C. : Normally Closed

ALARM-RESET TYPE:

N.O. : Normally Open

N.C. : Normally Closed

ALARM DURATION TIME: Alarm recording starts from the beginning of alarm and stops at the end of the duration or when alarm reset is activated. The max. duration is non-stop, the min. duration is 10 seconds.

PRE-ALARM OPERATION:

ON: Record the picture in pre-alarm recording speed in pre-alarm period.

OFF: No pre-alarm recording before alarm occurs.

RECORD SPEED: The recording speed in the pre-alarm period.

The max. recording speed is 50/60 IPS (PAL/NTSC).

The min. recording speed is 0.1 IPS.

Note

If the alarm occurs in standby or normal recording mode, the recording quality is the same as the normal recording quality. If the alarm occurs in timer recording mode, the recording quality is the same as the value set in timer recording quality.

4.5 Timer menu

The monitored image can be recorded automatically by setting the start and end times in the **TIMER MENU**.

There are 15 entries where a recording schedule for a particular day or set of days can be set for the week.

Move to an entry and press enter to select the day.

If you program for example the following:

START 09:00, STOP 23:59

Then recording starts at 09:00:00 and stops at 23:59:59.

To stop a timed recording while it is recording, press the **STOP** key to enter the **TIMER MENU** and change the **SET** value to **OFF**.

TIMER MENU						
WEEK	START	STOP	SPEED	QUALITY	SET	
SUN	00:00	00:00	002	HR	STANDARD	OFF
MON	00:00	00:00	002	HR	STANDARD	OFF
WDAY	00:00	00:00	002	HR	STANDARD	OFF
WEND	00:00	00:00	002	HR	STANDARD	OFF
DLY	00:00	00:00	002	HR	STANDARD	OFF
MON	00:00	00:00	002	HR	STANDARD	OFF
TUE	00:00	00:00	002	HR	STANDARD	OFF
FRI	00:00	00:00	002	HR	STANDARD	OFF
THU	00:00	00:00	002	HR	STANDARD	OFF
WED	00:00	00:00	002	HR	STANDARD	OFF
SAT	00:00	00:00	002	HR	STANDARD	OFF
SUN	00:00	00:00	002	HR	STANDARD	OFF
MAIN MENU						>

WEEK: Selects the day or set of days for the timer.

DLY: every day

WDAY: Monday to Friday

WEND: Saturday and Sunday

Individual days of the week

START: Enter the start time for timer recording.

STOP: Enter the end time for timer recording.

STOP time needs to be later than the START time.

(e.g. START 16.00, STOP 03.00 is not correct

START 16.00, STOP 00.00 is not correct

START 16.00, STOP 23.59 is correct

SPEED: When **SPEED FORMAT** set by **HR**, the recording speed can be set from 4/6 (NTSC/PAL) HR to 960HR.

When **SPEED FORMAT** set by **IPS**, the recording speed can be set from 0.1 ~ 30/0.1 ~ 25(NTSC/PAL)IPS.

QUALITY: There are six recording picture quality levels

LOWER: 15 KB

LOW: 20 KB

BASIC: 25 KB

STANDARD: 30 KB

HIGH: 35 KB

SUPERIOR: 40 KB

SET: Set ON when using timer recording.

Set OFF when not using timer recording.

In **Timer Recording** mode, the **OSD** shows the **Timer date/time** and the **Timer recording rate** appears under **T.REC**.

You cannot change the quality level for continuous recording. For example:

Seg 1 08:30~17:00

Seg 2 17:00~23:59

Seg 1 and Seg 2 are treated as the continuous recording 08:30~23:59.

If you need to set different quality level, set as follows:

Seg 1 08:30~16:59

Seg 2 17:00~23:59

4.6 Buzzer menu

BUZZER MENU	
BUZZER OPERATION	ENABLE
ALARM-IN	ON
RECORD-IN	ON
DISK FULL	ON
VIDEO LOSS	ON
TIMER	OFF
MAIN MENU	>

BUZZER OPERATION:

ENABLE: Select buzzer to be on.

DISABLE: Select buzzer to be off.

Note: Press Enter button to enable/disable in Record/Playback mode.

ALARM-IN: ON - the buzzer sounds when the alarm occurs.

RECORD-IN: ON - the buzzer sounds when Record-IN signal is applied on the Record-IN terminal.

DISK FULL: ON - the buzzer sounds when disk is nearly full 99.7%

VIDEO LOSS: ON - the buzzer sounds when the video signal is lost.

TIMER: ON - the buzzer sounds when timer record occurs.

4.7 Archive menu

ARCHIVE MENU	
PICTURE SIZE	720 X 576
TIME STAMP	ON
TIME STAMP POSITION	BOTTOM
WATER MARK	ON
WATER MARK POSITITON	BOTTOM
MAIN MENU	>

PICTURE SIZE: Select picture size for copying image to CF card
 Big size: 720x576 (PAL), 720x480 (NTSC)
 Small size: 352x288 (PAL), 352x240 (NTSC)

TIME STAMP:
 ON: Time stamp appears on the picture when copying image to CF card.

OFF: Time stamp does not appear on the picture when copying image to CF card.

TIME STAMP POSITION:
 BOTTOM: Time stamp appears at the bottom
 TOP: Time stamp appears at the top

WATER MARK:
 ON: Water mark appears on the picture when copying image to CF card.
 OFF: Water mark does not appear on the picture when copying image to CF card.

WATER MARK POSITION:
 BOTTOM: Water mark appears at the bottom
 TOP: Water mark appears at the top.

When YES is set for PASSWORD ENABLE, a password is required to enter the menu. The code is six digits long and can be any digit from 1 to 5.

If you have activated the password, whenever you press the menu button in live mode or stop button in record mode the system asks you to enter the password. Therefore, be sure to make a note of the password.

MULTIPLEXER: The following settings are available:

OFF: Select if only one camera is connected to the DVR. The main monitor output is same as the video out connector all the time.

MAKE OF MULTIPLEXER: Selection for various types of multiplexer (e.g. BOSCH LTC2600). When a multiplexer is selected, the video input from the MUX MAIN MONITOR connector at the rear panel is looped through to the MONITOR OUT when the recorder is not in MENU mode.

UNKNOWN: Select if your multiplexer is not listed and you don't have a custom code.

CUSTOM: Select if you have a custom code for your multiplexer model. Enter the parameters in the CUSTOM MULTIPLEXER PARAMETER menu.

CUSTOM MULTIPLEXER MENU			
PARAMETER PAIR 1	000	000	
PARAMETER PAIR 2	000	000	
PARAMETER PAIR 3	000	000	
PARAMETER PAIR 4	000	000	
PARAMETER PAIR 5	000	000	
PARAMETER PAIR 6	000	000	
PARAMETER PAIR 7	000	000	
PARAMETER PAIR 8	000	000	
SYSTEM SETTINGS MENU	>		

4.8 System settings menu

SYSTEM SETTINGS MENU	
PASSWORD ENABLE	NO
PASSWORD	555555
MULTIPLEXER	Bosch LTC2600
FIELD CODE LINE	13
DISK FULL	REWRITE
SPEED FORMAT	BY IPS
VIDEO SYSTEM	PAL
ERASE DISK	>
SYSTEM UPDATE	>
LOAD DEFAULT	>
CF FORMAT	>
MAIN MENU	>

PASSWORD ENABLE:
 YES: PASSWORD required to enter the menu.
 NO: PASSWORD not required to enter the menu.
 PASSWORD :

PARAMETER PAIR:

In the CUSTOM MULTIPLEXER menu, you can fill-in a custom code for a particular model of multiplexer. Consult you sales representative for information on these codes.

FIELD CODE LINE:

If you set the multiplexer make to UNKNOWN, you can adjust the field code line of the connected multiplexer between 0 and 20. The default (13) is suitable for most multiplexers. If the field code line appears at the top of the playback channels, decrease the value. If multiplexers do not playback correctly, increase the value.

DISK FULL:

STOP : When disk is full, the machine stops recording.

REWRITE : When disk is full, the current video overwrites the existing video from the beginning of the hard disk.

SPEED FORMAT: Select recording speed by IPS (Images per second) or Hour

VIDEO SYSTEM: Select the video system NTSC or PAL (requires power reset to activate).

ERASE DISK:

Press Enter to erase all recording from the hard disk.
The confirmation dialog box appears on the screen.
Select Yes or No and then press ENTER.

SYSTEM UPDATE:

Press Enter to update the system or not.
YES: Copy the update file onto the Compact Flash card on the PC and then insert the Compact Flash card into the slot.
Press ENTER key to update the system. After the system is updated successfully, be sure to reset the power to activate.

LOAD DEFAULT:

Press Enter to load the factory default or not.
YES: The confirmation dialog box appears on the screen.
Select Yes or No and then press ENTER.

CF FORMAT:

YES: will format the Compact Flash card.
NO: will not format the Compact Flash card.

4.9 Password menu

When password protection is enabled, a password menu appears on the screen when you try to open a menu or stop recording. You must enter the password using the following keys:

REC : 1

OSD : 2

STOP : 3

PLAY : 4

PAUSE : 5

5 Specifications

5.1 RS-232 interface

The DVR can be controlled by a computer or a terminal via the standard D-SUB 9-pin RS-232 connector.

Pin DVR1C1161		Pin HOST	
1	NC	1	NC
2	TXD	2	RXD
3	RXD	3	TXD
4	NC	4	DTR
5	GROUND	5	GROUND
6	NC	6	DSR
7	NC	7	RTS
8	NC	8	CTS
9	+5V	9	NC

The transmission setting is 9600 baud rate, 8 data bits, 1 start bit, 1 stop bit and no parity.

5.1.1 RS-232 control protocol

A computer or a terminal can be used to control the unit by sending three character ASCII commands through the RS232 connector, these ASCII commands are started with 'K' or 'k'. There are 30 ASCII commands mapped to the 30 keypads in the front panel. The 30 ASCII commands are shown on the following table.

ASCII CODE	FUNCTION	Keypad in front panel
K01	Start Recording	REC
K03	Stop Recording and Playing back	STOP
K04	Playing back	PLAY
K05	Pause the playback picture	PAUSE
K06	Search playback	SEARCH
K00	Copy picture into CF card	COPY
K02	On screen display	DISPLAY
K07	Confirm the selection	ENTER
K08	Enter Setting Menu	MENU
K09- K15	Fast reverse playback speed	<< 1-640 x, 1/2-1/64
K16 - K22	Fast playback speed	>> 1-640 x, 1/2-1/64
K23	Rewind the still image	JOG-REW
K24	Advance the still image	JOG-FF

5.2 Recording time

Approximate recording times in hours when recording with a 80-GB hard disk.

PAL							
Recording Rate (IPS)	Recording Speed (Hour)	Picture Quality (average file size)					
		Lower (15KB)	Low (20KB)	Basic (25KB)	Standard (30KB)	High (35KB)	Superior (40KB)
		Approximate Recording Time Hours / weeks					
50	3	30	22	18	15	13	11
25	6	59	44	36	30	25	22
12	18	119	89	71	59	51	44
8	30	178	133	107	89	76	67
5	48	296	222	178	148	127	111
2	72	711	533	427	356	305	267
1.6	120	948	711	569	474	406	356
1.0	168	1481	1111	889	741	635	556
0.5	240	2963	2222	1778	1481	1270	1111
0.2	480	7407	5556	4444	3704	3175	2778
0.1	960	14815	11111	8889	7407	6349	5556

NTSC							
Recording Rate (IPS)	Recording Speed (Hour)	Picture Quality (average file size)					
		Lower (15KB)	Low (20KB)	Basic (25KB)	Standard (30KB)	High (35KB)	Superior (40KB)
		Approximate Recording Time Hours / weeks					
60	3	25	19	15	12	11	9
30	6	49	37	30	25	21	19
20	18	74	56	44	37	32	28
10	30	148	111	89	74	63	56
5	48	296	222	178	148	127	111
2	72	741	556	444	370	317	278
1.5	120	988	741	593	494	423	370
1.0	168	1481	1111	889	741	635	556
0.5	240	2963	2222	1778	1481	1270	1111
0.2	480	7407	5556	4444	3704	3175	2778
0.1	960	14815	11111	8889	7407	6349	5556

Reference:

24H=1 day, 168H=1 week, 720H=1 month,

8760H=1year

(Estimated with typical image-low noise level)

5.3 Technical specifications

Video

Format	PAL/NTSC
Input	1 camera input (BNC), 1Vpp, 75Ohm
Output	1 video output (BNC) for main monitor, 1Vpp, 75Ohm
Compression	M-JPEG
Resolution	720 x 576 (PAL) / 720 x 484 (NTSC)
Display	Full display for live and playback

Alarm

Input	Switching voltage High: > 2 Vdc Switching voltage Low: < 0.5 Vdc
Output	One relay output: Contact voltage max.: 24 Vdc Switching current max.: 2A dc

Storage

Hard disk	80 Gb
-----------	-------

Recording

Mode	Continuous, time-lapse, schedule or event recording
Rate	Max. 50 images per sec. (PAL) Max. 60 images per sec. (NTSC)

Playback

Rate	Max. 50 images per sec. (PAL) Max. 60 images per sec. (NTSC)
Search	Date/time, segment list or event (alarm)

General

Video loss detection	Yes
Power loss detection	Yes
Alarm log	Yes
User interface	Menu-driven
Setup	By on-screen display menu
User input device	Front panel keypad, remote control (IR with wired receiver) optional
Image export	Built-in Compact Flash slot for Type I and Type II cards
Security	Password protection
Power supply	100 - 240 Vac, 50/60 Hz
Power consumption	< 40 W
Timer	Weekly timer, built-in real time clock
Control connection	RS-232, 9-pin D-Sub connector

Mechanical

Weight	approx. 5.5 kg / 11.5 lbs
Dimensions (WxHxD)	346 x 88 x 269 mm 13.6 x 3.5 x 10.5 inches
Ambient temperature	
Operating	+0°C ... +40°C +32°F ... +104°F

Approvals

Safety

Europe	EN60950
USA	UL60950 UL & cUL listed
Australia	C-Tick

Electro Magnetic Compatibility (EMC)

Europe	EN55022 Class B, EN50130-4
USA	FCC part 15, class B
Australia	AS/NZS 3548

Specifications may change without notice. If you have any problems, contact your dealer.

